VALVE ELECTRONIC CVII2

Specification MAP/CV112/Issue 5 Dated 15.1.49 To be read in conjunction with K1002

SECURITY Specification RESTRICTED

Valve UNCLASSIFIED

Indicates change

FREQUENCY RANGE The crystal valve is intended to Crystal Valves operate within a frequency range:-12,000 - 6,000 Mg/s (2.5 - 5.0 cms).

MARKING

An orange and green spot or CV112.

> PACKING See Kl005

DIMENSIONS

See K1002/AI.

CVII2

	K1002 Para. ref.	Test	Limits	No. Tes te d	Note
a	6.2	Back to forward resistance ratio	10 : 1 min.	100%	1
b	6.3	Forward resistance (0)	250 max.	100%	1
С	6.4.2	Resistance to Voltage Breakdown	After application of 4.5V. and a wait of not more than 2 mins. test 'd' shall be applied.	100%	
đ	6.4.3	Test 'a' and 'b' repeated.	See tests 'a' and 'b' above.	100%	
е	6.5	Noise factor	At some point in the frequency range 10,700 - 8,600 Mc/s (2.8 - 3.5 cms.) Max. predicted NF, 14 db. S.P.G.	100%	

NOTES

- 1 This figure applies only to the factory test. Subsequently the back to forward resistance ratio may fall and the forward resistance rise, when crystal valves within the following limits may be regarded as satisfactory for operational use:-
 - (a) Back to forward resistance ratio (min.) 8:1 (b) Forward resistance (Max.) 2650
- Tests 'a', 'b' and 'e' are repeatable. Test 'c' is non-repeatable.